

# FORTRAN



1. Remove the four screws on the door in order to take the LED out of the housing.
2. Remove the LED from the housing.
3. If the gasket is worn, replace it with one provided (if applicable).
4. Take the snow shield and place behind the door of the housing, ensuring that the top of the snow shield is inline with the top of the door.
5. Place the LED back into the housing and securely screw the door back into place.

